

DR603-Instruction for Binding Card



1. First, turn on the display that we need to bind the card to.

2. Prepare the universal card and the card that needs to be newly bound.



3. Put the universal card on either side of the screen, the moment that the card touches the screen, the display screen will switch from the "NFC" interface to the "main" interface, within 15 seconds, put the universal card on either side of the screen again for 3 seconds, and the display will enter the card binding interface.



4. After re-entering the card binding interface, you can bind the new card to the display, the interface will change from the current number when you bind the card.

Example: The current number is C-3; after binding one card, it will become C-4.

Note: The card binding value is 1-4 (this value cycles). After binding the fourth card, it will change from C-4 to C-1. If you continue binding cards in the C-1 state, the cards bound to the previous cycle's C-1 number will be overwritten, and so on.



4. After binding the card, press any key on the display to confirm. The display will then enter the main interface, indicating the card binding process is complete.

Note: If you remain on the card binding screen for more than 25 seconds, the display will still enter the main interface, card binding in this state is invalid. You must press any key to confirm after binding is complete, at this moment to enter the main interface and confirm the operation is successful.